



Top Recommended Supplies for InfinityLab LC Series

InfinityLab Quick Connect Fitting

- Perfect column connections for HPLC and UHPLC systems
- Truly finger-tight connection
- Reliable and reusable fittings—long lasting and reseal tightly, and are stable up to 1300 bar
- Spring-loaded design to ensure zero-dead-volume

5067-5958 (for Agilent 1290 Infinity II & III System) InfinityLab Quick Connect Fitting Assembly Including Stainless Steel Capillary 0.12x150 mm

5067-6167 (for Agilent 1260 Infinity II & III System) InfinityLab Quick Connect Fitting Assembly Including Stainless Steel Capillary 0.17x150 mm

InfinityLab Flex Bench and Benchtop

- Move your instruments where you need them, when you need them
- Enables space optimization in your lab
- The easy way to configure your LC system, change modules, perform maintenance with your existing bench setup

5043-1759 InfinityLab Flex Bench*
or

5043-1740 InfinityLab Benchtop*

* with power strip, available in regions except Asia Pacific. For Asia Pacific please use part numbers for benches without power strip: **5043-1252** or **5043-1711**



InfinityLab Purging Bottle and Stay Safe caps starter Kit

- Reduces harmful solvent vapors from leaching into the air
- Prevents suction of air in LC lines
- Simplifies ease-of-use and ease-of-handling

5043-1340 InfinityLab Purging Bottle and Stay Safe caps starter Kit

InfinityLab Quick Change Inline Filter

- Prevents column clogging and column damage caused by particles
- Lowers operational costs with a robust filter housing
- Enables ease-of-use with finger-tight, tool-free replacement of filter disc

5067-1603 (for Agilent 1290 Infinity II & III System) InfinityLab Quick Change Inline Filter Assembly for UHPLC with 2.1 mm id, 0.2 µm Filter Discs
or

5067-1602 (for Agilent 1260 Infinity II & III System) InfinityLab Quick Change Inline Filter Assembly for HPLC with 4.6 mm id, 0.5 µm Filter Discs

