

## Agilent DNF-471(15nt) RNA Kit - Total RNA

# **Quick Guide**

For Research Use Only. Not for use in diagnostic procedures

This Quick Guide is intended for use with the Agilent 5200, 5300, and 5400 Fragment Analyzer systems only. The DNF-471 RNA kit is designed to detect Total RNA within the range of 5  $ng/\mu L$  to 500  $ng/\mu L$  input sample concentration. A separate quick guide (D0118111) covers the use of DNF-471 RNA Kit for analyzing *in vitro* transcribed (IVT) mRNA.

## Specifications

Analytical Specifications <sup>1</sup>	RNA (15 nt) Kit <sup>1</sup>
Sizing Range	200 nt - 6,000 nt
Sizing Accuracy <sup>1</sup>	<u>±</u> 5%
Sizing Precision <sup>1</sup>	5% CV
Limit of Detection (S/N > 3)	5 ng/µL
Qualitative Range (per smear)	5 ng/μL – 500 ng/μL
Quantitative Range (per smear)	25 ng/μL – 500 ng/μL
Quantification Accuracy <sup>1</sup>	<u>+</u> 20%
Quantification Precision <sup>1</sup>	10% CV
Physical Specifications	
Total Electrophoresis Run Time	22cm <sup>2</sup> : 31 minutes, 33cm: 40 minutes, 55cm: 70 minutes
Samples Per Run	12, 48 or 96; depending on the instrument type
Sample Volume Required	2 μL
Guaranteed Shelf Life	4 months

Results using RNA Ladder as sample

<sup>&</sup>lt;sup>2</sup> The FA 12-Capillary Array Ultrashort, 22 cm is only available for the 5200 Fragment Analyzer system

## **DNF-471 Total RNA Kit Quick Guide**

## Kit Components - 500 Sample Kit - Refer to product label for proper storage conditions

Kit Component Number	Part Number (Re-order Number)	Description	Quantity Per Kit
5191-6572*		RNA (15 nt), 500, 4°C	
	DNF-265-0240	RNA Separation Gel, 240 mL	1
	DNF-300-0008	BF-25 Blank Solution, 8 mL	1
	DNF-355-0125	5x 930 dsDNA Inlet Buffer, 125 mL	1
	DNF-497-0125	0.25x TE Rinse Buffer, 125 mL	1
DNF-471-FR*		RNA (15 nt), FR	
	DNF-600-U030	Intercalating Dye, 30 µL	1
	DNF-369-0004	RNA Diluent Marker (15 nt), 4 mL	3
	DNF-382-U020	RNA Ladder, 20 μL	5
DNF-475-0050	DNF-475-0050	5x Capillary Conditioning Solution, 50 mL	1

## Kit Components – 1000 Sample Kit – Refer to product label for proper storage conditions

Part Number (Re-order Number)	Description	Quantity Per Kit
	RNA (15nt), 1000, 4°C	
DNF-265-0500	RNA Separation Gel, 500 mL	1
DNF-300-0008	BF-25 Blank Solution, 8 mL	1
DNF-355-0300	5x 930 dsDNA Inlet Buffer, 300 mL	1
DNF-497-0125	0.25x TE Rinse Buffer, 125 mL	1
	RNA (15 nt), FR	
DNF-600-U030	Intercalating Dye, 30 μL	2
DNF-369-0004	RNA Diluent Marker (15 nt), 4 mL	6
DNF-382-U020	RNA Ladder, 20 μL	10
DNF-475-0100	5x Capillary Conditioning Solution, 100 mL	1
	(Re-order Number)  DNF-265-0500  DNF-300-0008  DNF-355-0300  DNF-497-0125  DNF-600-U030  DNF-369-0004  DNF-382-U020	RNA (15nt), 1000, 4°C

<sup>\*</sup>Not orderable.

Altering any reagents and/or use of unapproved or non-recommended reagents may materially alter the performance of the instrument such that the instrument no longer performs to Agilent specifications. Any work performed by Agilent to bring the instrument back into compliance with Agilent specifications will be performed at the customer's expense.

#### Additional Material Required for Analysis with Fragment Analyzer Systems (not supplied)

Instrument	Compatible Arrays	Part Number	
5200 Fragment Analyzer	FA 12 Capillary Array Ultrashort FA 12 Capillary Array Short FA 12 Capillary Array Long	A2300-1250-2247 A2300-1250-3355 A2300-1250-5580	
5300 Fragment Analyzer.	FA 48 Capillary Array Short FA/ZAG 96 Capillary Array Short FA/ZAG 96 Capillary Array Long	A2300-4850-3355 A2300-9650-3355 A2300-9650-5580	
5400 Fragment Analyzer	FA/ZAG 96 Capillary Array Short FA/ZAG 96 Capillary Array Long	A2300-9650-3355 A2300-9650-5580	

### Software Reagents

- Fragment Analyzer controller software
- ProSize data analysis software

#### Capillary Storage Solution (GP-440-0100)

## Additional equipment required (not supplied)

- 96-well PCR sample plates (Refer to Appendix in Fragment Analyzer User Manual)
- Multichannel pipettor and/or liquid handling device capable of dispensing 1-100 μL (sample plates) and 1,000 μL (inlet buffer plate)
- Pipette tips
- 96-well plate centrifuge
- Adhesive PCR plate seals
- Sub-micron filtered DI water system: for dilutions.
- 96-deepwell 1 mL plate: inlet buffer and/or waste plate (Agilent #P60-20 or Fisher Scientific #12-566-120)
- Reagent reservoir 50 mL: for use in pipetting inlet buffer plates (VWR #89094-680, or similar)
- Conical centrifuge tubes for prepared separation gel+dye mixture and/or 1x Capillary Conditioning Solution
  - o 50 mL for 5200 Fragment Analyzer system (BD Falcon #352070, Fisher Scientific #14-432-22 or VWR #21008-940)
  - o 250 mL for 5300 and 5400 Fragment Analyzer systems (Corning #430776, Fisher Scientific #05-538-53 or VWR #21008-771)
- Vortexer (VWR, part number 102093-352)
- RNase-free/nuclease free water
- RNaseZap (Ambion #AM9782 or equivalent product)
- Thermal cycler
- Eppendorf DNA LoBind® tubes for aliquoting RNA Ladder (Eppendorf p/n 022431021)



#### Working with Chemicals

- · Refer to product safety data sheets for further information
- When working with the Fragment Analyzer kit components follow the appropriate safety procedures such as wearing personal protective equipment (PPE).

#### **Essential Measurement Practices**

Environmental conditions	<ul> <li>Ambient operating temperature: 19 - 25 °C (66 - 77 °F)</li> <li>Keep instrument reagents at room temperature during sample preparation.</li> </ul>
Sample input concentration	<ul> <li>Ensure sample input concentrations lie within kit specifications.</li> <li>Sample signal should not exceed 60,000 RFU.</li> </ul>
Working with RNA Samples	<ul> <li>Ensure all working areas, reagents and plastic ware are RNase free.</li> <li>Handle RNA samples with care.</li> <li>Wear gloves at all times.</li> <li>Thaw RNA samples on ice.</li> <li>Vortex and centrifuge all samples before use.</li> <li>Store RNA samples on ice throughout the preparation and analysis procedure.</li> </ul>
Steps before sample preparation	<ul> <li>Allow instrument reagents to equilibrate at room temperature for 30 min prior to use.</li> <li>Thaw RNA ladder on ice prior to use.</li> <li>Keep RNA Diluent Marker on ice before use. Vortex the tube briefly to mix the contents.</li> </ul>

#### **DNF-471 Total RNA Kit Ouick Guide**

#### Pipette reagents against the side of the 96-well sample plate or sample tube. Pipetting practice Ensure no sample or Diluent Marker remains within or on the outside of the tip. Upon arrival of the ladder, it is recommended to divide the ladder into aliquots with working volume typical for one day use or one sample plate. Store aliquots in Eppendorf 0.5 mL LoBind tubes (Eppendorf p/n 022431021) at -70°C or below. Thaw RNA ladder aliquot in PCR tube on ice. **RNA Ladder** Spin down the contents and mix by pipetting the solution up and down with a pipette tip. Preparation Transfer the Ladder to a RNase-free PCR tube. Heat denature the ladder at 70°C for 2 minutes, immediately cool to 4°C and keep on ice. The RNA ladder must be run in parallel with the samples for each experiment to ensure accurate quantification. Heat-denature all total RNA samples at 70°C for 2 minutes if needed and immediately cool to 4°C and keep on ice before use. Total RNA Sample The total RNA input sample must be within a total concentration range of 5 ng/µL - 500 Preparation ng/µL for optimal kit results. If the concentration of the sample is above this range, dilute with RNase-free water. Using a fresh RNase-free 96-well sample plate, pipette 22 µL of the RNA Diluent Marker (DM) solution to each well in a row that is to contain sample or RNA Ladder. Fill any unused wells within the row of the sample plate with 24 µL blank solution. Sample Plate Pipette 2 µL of each denatured RNA sample into the 22 µL of DM solution in the Preparation respective wells of the sample plate; mix well contents by aspiration/expulsion in the pipette tip. Pipette 2 µL of denatured RNA Ladder into the 22 µL of DM solution in the designated ladder well. When mixing sample with Diluent Marker (DM), mix the contents of the well thoroughly. It is suggested to perform **one** of the following methods to ensure complete mixing. After adding 2 µL of sample or ladder to the 22 µL of DM, place a plate seal on the sample plate and vortex the sample plate at 3,000 rpm for 2 min. Avoid intense vortexing that causes splashing. The plate should be spun via a centrifuge after vortexing to ensure there are no trapped air bubbles in the wells. Mixing and After adding 2 µL of sample or ladder to the 22 µL of DM, use a separate pipette tip centrifugation set to a larger 20 µL volume, and pipette each well up/down to further mix. recommendations Use an electronic pipettor capable of mixing a 10 µL volume in the tip after

- Use an electronic pipettor capable of mixing a 10 μL volume in the tip after dispensing the 2 μL sample or ladder volume.
- Fill any unused wells within the row of the sample plate with 24 µL Blank Solution.
- After mixing, centrifuge the plate to remove any air bubbles.
- Run samples immediately after preparation, or within a day. If not using right away, cover and keep at 4°C, warm to RT and centrifuge before running plate.

## **Gel Preparation**

Centrifuge dye prior to opening the vial to reduce risk of leaking. Ensure the gel + dye is mixed without generating bubbles, gently invert tube 5-10 times.

Number of Samples	Intercalating Dye Volume (μL)	Separation Gel Volume (mL)
12	1	10
24	1.5	15
48	2.5	25
96	4.5	45
192	8	80
384	16	160

## **Conditioning Solution**

The provided 5X Conditioning Solution <u>must be diluted</u> to 1X using submicron DI water prior to use. Invert to mix.

Number of Samples	Volume of 1X Conditioning Solution (mL)
12	10
24	15
48	25
96	45
192	80
384	160

#### Agilent RNA DNF-471 Kit Operating Procedure

- 1. Mix fresh gel and dye according to the volumes in the preparation table. Update solution level in controller software.
- 2. Refill 1X Capillary Conditioning Solution as needed. Update solution level in controller software.
- 3. Inspect and empty, if necessary, waste plate located in drawer 'W".
- 4. Place a fresh 1X Inlet Buffer, 1 mL/well, in drawer "B". Replace daily.
  - 5200 row A
  - 5300 48 capillary, rows A-D
  - 5300/5400 96 capillary, all rows

Prepare Capillary Storage Solution plate. Replace every 2 weeks for optimal results.


- 5200 row H, 1 mL/well, drawer B
- 5300 48 capillary, rows A-D, 100 μL/well, drawer 3
- 5300/5400 96 capillary, all rows, 100 μL/well, drawer 3

Place 0.25x TE Rinse Buffer plate, 200 µL/well, in drawer "M". Replace daily.

- 5200 Row A
- 5300 48 capillary, rows A-D
- 5300/5400 96 capillary, all rows
- 5. Mix samples or ladder with diluent marker in sample plate, add 24 µL of Blank Solution to unused wells. Place ladder in corresponding well (see sample plate image below), depending on capillary array used.
- 6. Select Row/Group/Tray to run. Enter sample ID and Tray ID, if desired.
- 7. Add to queue, from the dropdown select the corresponding method based on your capillary length;
  - DNF-471-22
  - DNF-471-33
  - DNF-471-55


Enter Tray Name, Folder Prefix and Notes, if desired.

8. Add method to the queue by selecting "OK", press play be to start the separation.



## **DNF-471 Total RNA Kit Quick Guide**

## RNA Ladder result



Representative RNA Ladder result using the Fragment Analyzer system with the DNF-471 RNA kit (15 nt). Peaks annotated by size (nt) Method: DNF-471-33. RFU values may differ between instruments.

## Troubleshooting

The following table lists several potential kit specific issues which may be encountered when using the DNF-471 RNA kit (15 nt) and suggested remedies. Contact Agilent technical support if you have any additional troubleshooting or maintenance questions.

Issue	Cause	Corrective Action
Sample and/or ladder signal too weak.	1 Sample and/or ladder degraded.	Make sure to store ladder at -70°C and keep on ice before use. Use fresh sample and/or ladder.
	2 Diluent marker degraded.	2 Make sure the diluent marker is stored at -20°C and keep on ice before use. Use a new vial of diluent marker.
	3 Sample, ladder and/or diluent marker are contaminated.	3 Clean working area and equipment with RNaseZap. Always wear gloves when preparing sample/ladder. Use new sample, ladder aliquot, and diluent marker.
	4 Sample concentration is too low and out of range.	4 Verify sample was within concentration range specified for the DNF-471 RNA kit (15 nt). Prepare sample at higher concentration; OR Analyze sample using High Sensitivity RNA kit DNF-472.
	5 Sample not added to Diluent Marker solution or not mixed well.	5 Verify sample was correctly added and mixed to sample well.
Missing 25S or 28S ribosomal peak.	Sample concentration too high and out of range.	Verify sample was within     concentration range specified for     the RNA kit.
	2 If sample is insect total RNA,heat denaturing can cause the 28S peak of some samples to cleave, causing incorrect RQN.	<ol> <li>Run insect total RNA sample without heat denaturing.</li> </ol>
Split RNA peak.	Sample's salt concentration was too high.	Take steps to lower the salt content in the sample and repeat experiment.

## **DNF-471 Total RNA Kit Quick Guide**

	2 Sample was not heat denatured.	2 Heat denature sample/ladder plate at 70°C for 2 minutes.
Peak too broad, signal too low and/or migration time too long.	Capillary array needs to be reconditioned.	Flush array with 0.5 N NaOH solution and repeat experiment. (See Appendix     Capillary Array Cleaning of the Fragment Analyzer User Manual for details).
	2 Capillary array vent valve is clogged.	<ol> <li>Clean vent valve with deionized water (See Fragment Analyzer User Manual for details).</li> </ol>
Peak too broad, signal too low and/or migration time too long.	Capillary array needs to be reconditioned.	<ol> <li>Flush array with 0.5 N NaOH solution and repeat experiment. (See Appendix         <ul> <li>Capillary Array Cleaning of the Fragment Analyzer User Manual for details).</li> </ul> </li> </ol>
	2 Capillary array vent valve is clogged.	<ol><li>Clean vent valve with deionized water (See Fragment Analyzer User Manual for details).</li></ol>
No sample peak or marker peak observed for individual sample.	1 Air trapped at the bottom of the sample plate well, or bubbles present in sample well.	Check sample plate wells for trapped air bubbles. Centrifuge plate.
	2 Insufficient sample volume. A minimum of 20 µL is required.	Verify proper volume of solution was added to sample well.
	3 Capillary is plugged.	3 Check waste plate for liquid in the capillary well using 96-deepwell plate. If no liquid is observed, follow the steps outlined in the System Manual for unclogging a capillary array.

## For Research Use Only

Not for use in diagnostic procedures.

## Technical Support and Further Information

For technical support please visit www.agilent.com which offers useful information and support regarding the products and technology.

## www.agilent.com

© Agilent Technologies, Inc 2025

SD-AT000131 Edition 03/25

