

Agilent DNF-472 (15 nt) HS RNA Kit IVT mRNA

Quick Guide

For Research Use Only. Not for use in diagnostic procedures

This Quick Guide is intended for use with the Agilent 5200, 5300, and 5400 Fragment Analyzer systems only. The DNF-472 HS RNA kit has methods for analysis of IVT mRNA as well as Total RNA and ribo-depleted RNA samples. This quick guide covers the two methods for IVT mRNA a low concentration range of 500 to 2,500 pg/ μ L and a mid-concentration range of 2,500 to 10,000 pg/ μ L, as well as the corresponding Extended methods for IVT mRNA > 6,000 nt. A separate quick guide (SD-AT000132) covers Total RNA and ribo-depleted RNA methods.

Specifications

Analytical Specifications ¹	HS RNA (15 nt) Kit	
	Low Concentration	Mid Concentration
Method	DNF-472A33 – HS IVT mRNA Low Concentration	DNF-472B33 – HS IVT mRNA Mid Concentration
Sizing Range	200 nt - 6,000 nt	200 nt – 6,000 nt
Sizing Accuracy ¹	±15%	±15%
Size Precision ¹	<10% CV	<5% CV
Sensitivity ¹	15 pg/μL	N/A
Input Concentration Rage ¹	500 pg/μL -2,500 pg/μL	2,500 pg/μL -10,000 pg/μL
Extended Method	Low Concentration	Mid Concentration
	DNF-472AE33-HS IVT mRNA Extended Low Concentration	DNF-472BE33 – HS IVT mRNA Extended Mid Concentration
Sizing Range	500 nt – 9,000 nt with Lonza RNA Marker	500 nt – 9,000 nt with Lonza RNA Marker
Sizing Accuracy ¹	±15%	±15%
Size Precision ¹	<10% CV	<5% CV
Sensitivity ¹	15 pg/ μL	N/A
Input Concentration Rage ¹	500 pg/μL -2,500 pg/μL	2,500 pg/μL -10,000 pg/μL
Physical Specifications		
Total Electrophoresis	33cm: 45 minutes	
Run Time	33cm: 90 minutes Extended Method	

Samples Per Run	12, 48 or 96; depending on the instrument type
Sample Volume Required	2 μL
Guaranteed Shelf Life	4 months

Results using 1,800 nt, 4,300 nt, and 9,000 nt IVT mRNA with no modifications on the 5200 and 5300 Fragment Analyzer instruments with the FA Capillary Array Short, 33 cm.

Kit Components – 500 Sample Kit – Refer to product label for proper storage conditions

Kit Component Number	Part Number (Re-order Number)	Description	Quantity Per Kit
5191-6574*		HS RNA (15 nt), 500, 4 °C	
	DNF-265-0240	RNA Separation Gel, 240 mL	1
	DNF-301-0008	BF-1 Blank Solution, 8 mL	1
	DNF-355-0125	5x 930 dsDNA Inlet Buffer, 125 mL	1
	DNF-497-0250	0.25x TE Rinse Buffer, 250 mL	1
DNF-472-FR*		HS RNA (15 nt) FR	
	DNF-600-U030	Intercalating Dye, 30 µL	1
	DNF-370-0004	HS RNA Diluent Marker (15 nt), 4 mL	3
	DNF-386-U015	HS RNA Ladder, 15 μL	1
5191-6612*		Quantitative DNA, RT	
	C275-130	Eppendorf LoBind 0.5 mL tubes (bag of 50)	1
	DNF-475-0050	5x Capillary Conditioning Solution, 50 mL	1

Kit Components – 1000 Sample Kit – Refer to product label for proper storage conditions

Kit Component Number	Part Number (Re-order Number)	Description	Quantity Per Kit
5191-6575*		HS RNA (15 nt), 1000, 4 °C	
	DNF-265-0500	RNA Separation Gel, 500 mL	1
	DNF-301-0008	BF-1 Blank Solution, 8 mL	1
	DNF-355-0300	5x 930 dsDNA Inlet Buffer, 300 mL	1
	DNF-497-0250	0.25x TE Rinse Buffer, 250 mL	1
DNF-472-FR*		HS RNA (15 nt), FR	
	DNF-600-U030	Intercalating Dye, 30 µL	2
	DNF-370-0004	HS RNA Diluent Marker (15 nt), 4 mL	6
	DNF-386-U015	HS RNA Ladder, 15 μL	2
5191-6613*		HS RNA (15 nt), 1000, RT	
	C275-130	Eppendorf LoBind 0.5 mL tubes (bag of 50)	1
	DNF-475-0100	5x Capillary Conditioning Solution, 100 mL	1

^{*}Not orderable.

Altering any reagents and/or use of unapproved or non-recommended reagents may materially alter the performance of the instrument such that the instrument no longer performs to Agilent specifications. Any work performed by Agilent to bring the instrument back into compliance with Agilent specifications will be performed at the customer's expense.

Additional Material Required for Analysis with Fragment Analyzer Systems (not supplied)

Instrument	Compatible Arrays	Part Number	
5200 Fragment Analyzer	FA 12 Capillary Array Short	A2300-1250-3355	
5300 Fragment Analyzer.	FA 48 Capillary Array Short FA/ZAG 96 Capillary Array Short	A2300-4850-3355 A2300-9650-3355	
5400 Fragment Analyzer	FA/ZAG 96 Capillary Array Short	A2300-9650-3355	

Software Reagents

- Fragment Analyzer controller software
- ProSize data analysis software

• Capillary Storage Solution (GP-440-0100)

Additional equipment required (not supplied)

- 96-well PCR samples plates (Refer to Appendix in Fragment Analyzer User Manual)
- Multichannel pipettor and/or liquid handling device capable of dispensing 1-100 μL (sample plates) and 1,000 μL (inlet buffer plate)
- Pipette tips
- 96-well plate centrifuge
- Adhesive PCR plate seals
- Sub-micron filtered DI water system: for instrument reagent dilutions
- 96-deepwell 1 mL plate: inlet buffer and/or waste plate (Agilent #P60-20 or Fisher Scientific #12-566-120)
- Reagent reservoir 50 mL; for use in pipetting inlet buffer plates (VWR #89094-680, or similar)
- Conical centrifuge tubes for prepared separation gel+dye mixture and/or 1x Capillary Conditioning Solution
 - o 50 mL for 5200 Fragment Analyzer system (BD Falcon #352070, Fisher Scientific #14-432-22 or VWR #21008-940)
 - o 250 mL for 5300 and 5400 Fragment Analyzer systems (Corning #430776, Fisher Scientific #05-538-53 or VWR #21008-771)
- Vortexer (VWR, part number 102093-352)
- RNase-free/nuclease free water RNA sample dilutions
- RNaseZap (Ambion #AM9782 or equivalent product)
- Thermal cycler
- Lonza RNA Marker when running Extended IVT mRNA method (Lonza p/n 50575)
- Eppendorf DNA LoBind® tubes for aliquoting RNA Ladder (Eppendorf p/n 022431021)

WARNING

Working with Chemicals

- Refer to product safety data sheets for further information
- When working with the Fragment Analyzer kit components follow the appropriate safety procedures such as wearing personal protective equipment (PPE).

Essential Measurement Practices

Environmental conditions	 Ambient operating temperature: 19 – 25 °C (66 – 77 °F) Keep instrument reagents at room temperature during sample preparation.
Sample Input Concentration	 Ensure sample input concentrations lie within kit specifications. Sample signal should not exceed 60,000 RFU.
Working with RNA	 Ensure all working areas, reagents and plastic ware are RNase free. Handle RNA samples with care. Wear gloves at all times. Thaw RNA samples on ice. Vortex and centrifuge all samples before use. Store RNA samples on ice throughout the preparation.
Steps before sample preparation	 Allow instrument reagents to equilibrate at room temperature for 30 min prior to use. Thaw HS RNA Ladder on ice prior to use. Keep HS RNA Diluent Marker on ice and in the dark throughout use. Vortex the tube briefly to mix the contents.
Pipetting practice	 Pipette reagents against the side of the 96-well sample plate or sample tube. Ensure no sample or Diluent Marker remains within or on the outside of the tip.
HS RNA Ladder Preparation	 The HS RNA Ladder is supplied at a concentration of 25 ng/μL. Upon arrival of the ladder it is recommended to divide the ladder into 3 μL aliquots. Store aliquots in the provided Eppendorf 0.5 mL LoBind tubes at -70°C or below. Thaw a 3 μL 25 ng/μL ladder aliquot on ice. Spin down the contents and mix by pipetting the solution up and down with a pipette tip set to a 2 μL volume. Transfer 2 μL of the 25 ng/μL Ladder to a fresh Eppendorf LoBind 0.5 mL tube. Heat denature the ladder at 70°C for 2 minutes, immediately cool to 4°C and keep on ice. Dilute the ladder solution to a working concentration of 2 ng/μL by adding 23 μL of RNase-free water and mixing well. Divide the diluted ladder solution into aliquots with a volume typical for one day use or one sample plate. Store aliquots in the provided Eppendorf LoBind 0.5 mL tubes at -70°C or below. If more than 2 μL of the 25 ng/μL is transferred for heat denaturing, be sure to add enough RNase-free water to dilute the ladder to the working concentration of 2 ng/μL. The 2 ng/μL working concentration HS RNA Ladder must be run in parallel with the samples for each experiment to ensure accurate sizing.
Extended Method Lonza RNA Marker (Lonza ladder) Preparation	 Use the Extended Method for analysis of IVT mRNA > 6,000 nt this was developed in conjunction with the Lonza RNA Marker (Lonza ladder), diluted in nuclease free water to a concentration of 2 ng/μL. Upon arrival of the Lonza ladder dilute to 25 ng/μL with nuclease free water and divide the ladder into 3 μL aliquots. Store aliquots in the provided Eppendorf 0.5 mL LoBind tubes at -70°C or below. Thaw a 3 μL 25 ng/μL Lonza ladder aliquot on ice. Spin down the contents and mix by pipetting the solution up and down with a pipette tip set to a 2 μL volume. 1. Transfer 2 μL of the 25 ng/μL Lonza ladder to a fresh Eppendorf LoBind 0.5 mL tube. 2. Heat denature the Lonza ladder at 70°C for 2 minutes, immediately cool to 4°C and keep on ice. Dilute the heat denatured Lonza ladder solution to a working concentration of 2 ng/μL by adding 23 μL of RNase-free water and mixing well. Divide the diluted ladder solution into aliquots with a volume typical for one day use or one sample plate. Store aliquots in the provided Eppendorf LoBind 0.5 mL tubes at -70°C or below. If more than 2 μL of the 25 ng/μL ladder is transferred for heat denaturing, be sure to add enough RNase-free water to dilute the ladder to the working concentration of 2 ng/μL. The 2 ng/μL working concentration Lonza ladder must be run in parallel with the samples for each experiment to ensure accurate sizing.
IVT mRNA Sample Preparation	 Heat-denature the IVT mRNA samples at 70°C for 2 minutes if needed and immediately cool to 4°C and keep on ice before use. The IVT mRNA input sample must be within a total concentration range of 500 to 2,500 pg/µL

for Low Concentration range or 2,500 to 10,000 pg/ μ L for Mid Concentration range to achieve optimal kit results. If the concentration of the sample is above this range, dilute with RNase-free water.

Sample Plate Preparation

- Using a fresh RNase-free 96-well sample plate, pipette 18 µL of the HS RNA Diluent Marker (DM) solution to each well in a row that is to contain sample or RNA Ladder.
- Fill any unused wells within the row of the sample plate with 20 µL of blank solution.
- ullet Pipette 2 μ L of heat denatured RNA sample into the respective wells of the sample plate.
- Thaw the denatured 2 ng/µL working concentration of the RNA Ladder on ice.
- Pipette 2 μ L of working concentration denatured RNA Ladder into the 18 μ L of DM solution in the designated ladder well.
- Input range of concentration should not exceed 60,000 RFU
- .
- When mixing sample with DM, mix the contents of the well thoroughly. It is suggested to perform one of the following methods to ensure complete mixing:
 - sample plate and vortex the sample plate at 3,000 rpm for 2 min. Avoid intense vortexing that causes splashing. The plate should be spun via a centrifuge after vortexing to ensure there are no trapped air bubbles in the wells.

Mixing and centrifugation recommendations

After adding 2 µL of sample or ladder to the 18 µL of DM, use a separate pipette tip set to a larger 18 µL volume, and pipette each well up/down to further mix.

After adding 2 µL of sample or ladder to the 18 µL of DM, place a plate seal on the

- \cdot Use an electronic pipettor capable of mixing a 10 μL volume in the tip after dispensing the 2 μL sample or ladder volume.
- After mixing, centrifuge the plate to remove any air bubbles.
- Run samples immediately after preparation. If not using right away, cover and keep at 4°C, warm to RT and centrifuge before running plate.

Gel Preparation

Centrifuge dye prior to opening the vial to reduce risk of leaking. Ensure the gel + dye is mixed without generating bubbles, gently invert tube 5-10 times.

Number of Samples	Intercalating Dye Volume (µL)	Separation Gel Volume (mL)
12	1	10
24	1.5	15
48	2.5	25
96	4.5	45
192	8	80
384	16	160

Conditioning Solution

The provided 5XConditioning Solution <u>must be diluted</u> to 1X using submicron DI water prior to use. Gently invert to mix.

Number of Samples	Volume of 1X Conditioning Solution (mL)
12	10
24	15
48	25
96	45
192	80
384	160

Agilent HS RNA DNF-472 Kit Operating Procedure

- 1. Mix fresh gel and dye according to the volumes in the preparation table. Update solution level in controller software.
- 2. Refill 1X Capillary Conditioning Solution as needed. Update solution level in controller software.
- 3. Inspect and empty, if necessary, waste plate located in drawer 'W".
- 4. Place fresh 1X Inlet Buffer, 1 mL/well, in drawer "B". Replace daily.
 - 5200 row A
 - 5300 48 capillary, rows A-D
 - 5300/5400 96 capillary, all rows

Prepare Capillary Storage Solution plate. Replace every 2 weeks for optimal results.


- 5200 row H, 1 mL/well, drawer B
 - 5300 48 capillary, rows A-D, 100 µL/well, drawer 3
- 5300/5400 96 capillary, all rows, 100 μL/well, drawer 3

Place fresh 0.25x TE Rinse Buffer plate, 200 µL/well, in drawer "M". Replace daily.


- 5200 Row A
- 5300 48 capillary, rows A-D
- 5300/5400 96 capillary, all rows
- 5. Mix samples and ladder with diluent marker in sample plate, add 20 µL of Blank Solution to unused wells. Place ladder in corresponding well (see sample plate image below), depending on capillary array used. Use Lonza RNA Marker for Extended Methods.
- 6. Select Row/Group/Tray to run. Enter sample ID and Tray ID, if desired.
- 7. Add to queue, from the dropdown select the corresponding method based on the sample type;
 - DNF-472A33 HS IVT mRNA Low Concentration
 - DNF-472AE33 HS IVT mRNA Extended Low Concentration
 - DNF-472B33 HS IVT mRNA Mid Concentration
 - DNF-472BE33 HS IVT mRNA Extended Mid Concentration

Enter Tray Name, Folder Prefix and Notes, if desired.

8. Add method to the queue by selecting "OK", press play 1 to start the separation.




HS RNA Ladder result



Representative HS RNA Ladder result using the Fragment Analyzer system with the DNF-472 HS RNA kit (15 nt). Method: DNF-472B33 - HS IVT mRNA Mid Concentration. Peaks annotated by size (nt). RFU values may differ between instruments.

IVT mRNA Sample: Smear analysis table using normal separation method


Typical result for a \sim 1,800 nt transcript at 5 ng/ μ L total input concentration. A Smear Analysis has been performed, as indicated by the dashed lines, between 1,600 and 2,800 nt. This allows the user to determine the percent purity and concentration of their peak of interest. The first peak corresponds to the 15 nt lower marker peak (LM).



Electropherogram of an ~1,800 nt IVT mRNA sample result using the Fragment Analyzer system with the DNF-472 RNA kit (15 nt) and the DNF-472B33 – HS IVT mRNA Mid Concentration run method. Peaks annotated by size (nt).

IVT mRNA extended separation method with Lonza RNA Marker


Typical result for the Lonza RNA Marker at the recommended dilution of 2 ng/µL. A total of 11 peaks should be observed with the sizes annotated in the figure below. The first peak corresponds to the 15 nt lower marker peak (LM).



Representative result for the Lonza RNA Marker diluted to 2 ng/µL using the Fragment Analyzer system with the DNF-472 HS RNA kit (15 nt) and the DNF-472BE33 – HS IVT mRNA Extended Mid Concentration run method. Peaks annotated by size (nt).

IVT mRNA sample: Smear analysis table using extended separation method

The figure below shows a typical result for a \sim 9,000 nt transcript at 5 ng/ μ L total concentration, using the Lonza RNA Marker. A Smear Analysis has been performed, as indicated by the dashed lines, between 8,000 and 11,000 nt. This allows the user to determine the percent purity and concentration of their peak of interest. The first peak corresponds to the 15 nt lower marker peak (LM).



Electropherogram of a ~9,000 nt IVT mRNA sample using the Fragment Analyzer system with the DNF-472 HS RNA kit (15 nt) and the DNF-472BE33 – HS IVT mRNA Extended Mid Concentration run method. Peaks annotated by size (nt).

Troubleshooting

The following table lists several potential kit specific issues which may be encountered when using the DNF-472 HS RNA kit (15 nt) and suggested remedies. Contact Agilent technical support if you have any additional troubleshooting or maintenance questions.

Issue	Cause	Corrective Action
Sample and/or ladder signal too	1 Sample and/or ladder degraded.	1 Use fresh sample and/or ladder.
weak or degraded.	2 Diluent marker degraded.	2 Make sure the diluent marker is stored at -20°C and keep on ice before use. Use a new vial of diluent marker.
	3 Sample, ladder and/or diluent marker are contaminated.	3 Clean working area and equipment with RNaseZap. Always wear gloves when preparing sample/ladder. Use new sample, ladder aliquot, and diluent marker.
	4 Sample concentration is too low and out of range.	4 Verify sample was within concentration range specified for the HS RNA kit (15 nt). Prepare sample at higher concentration.
	5 Sample not added to diluent marker solution or not mixed well.	5 Verify sample was correctly added and mixed to sample well.
	6 Rinse buffer is not fresh or a wrong rinse buffer is used.	6 Prepare a new rinse buffer plate with 200 μL/well 0.25x TE buffer.
	7 Array was contaminated.	7 Flush array with 0.5 N NaOH solution and repeat experiment. (See Appendix – Capillary Array Cleaning of the Fragment Analyzer User Manual for details).
Sample signal drops abruptly at the end of separation.	1 Separation concentration too high and out of range.	1 Verify sample was within concentration range specified for the HS RNA kit (15 nt).
Missing 6000 nt fragment in ladder.	No rinse buffer in Marker plate; wrong rinse buffer.	1 Use a fresh rinse buffer plate with 200 μL/well 0.25x TE buffer.
	2 Dirty array inlet.	2 Flush array with 0.5 N NaOH solution and repeat experiment. (See Appendix – Capillary Array Cleaning of the Fragment Analyzer User Manual for details).
	3 Aging array.	3 Replace the array with a new array, if issue persists, contact Agilent Technical Support.
Split RNA peak.	Sample's salt concentration was too high.	Take steps to lower the salt content in the sample and repeat experiment.
	2 Sample was not heat denatured.	2 Heat denature sample/ladder plate at 70°C for 2 minutes.
Peak too broad, signal too low and/or migration time too long.	Capillary array needs to be reconditioned.	Flush array with 0.5 N NaOH solution and repeat experiment. (See Appendix Capillary Array Cleaning of the

	2 Capillary array vent valve is clogged.	Fragment Analyzer User Manual for details).
		2 Clean vent valve with deionized water (See Fragment Analyzer User Manual for details).
No sample peak or marker peak observed for individual sample.	1 Air trapped at the bottom of the sample plate well, or bubbles present in sample well.	Check sample plate wells for trapped air bubbles. Centrifuge plate.
	2 Insufficient sample volume. A minimum of 20 μL is required.	2 Verify proper volume of solution was added to sample well
	3 Capillary is plugged.	3 Check waste plate for liquid in the capillary well using a 96-deepwell plate. If no liquid is observed, follow the steps outlined in the System Manual for unclogging a capillary array.

For Research Use Only
Not for use in diagnostic procedures.

Technical Support and Further Information

For technical support please visit www.agilent.com which offers useful information and support regarding the products and technology.

www.agilent.com

© Agilent Technologies, Inc 2025

D0117260 Edition 03/25

